

PARTS CATALOGUE

RV100 Forward Plate



ENGINE:

Honda GX160

PART NUMBER:

4812334803



General information

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.


For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!

RV100	1
Service, repair and wear part kits	
Kits-4812334803 Service, repair and wear part kits	. 2
Service, repair and wear part kits	
4812334977 Repair kit, shock-absorber	4
4812334976 Repair kit, transmission	
4812334975 Repair kit, exciter unit	
Refurbishing kits	
4812334974 Refurbishing kit - covering	7
Field kits	
4812334980 Vulkollan Plat	. 8
4812334979 Transport wheels	
4812334978 Comfort handle	10
Lubricants	
Engine with Frame	
Engine with Frame	12
Service parts	15
Base Plate with Exciter Unit	
Base Plate with Exciter Unit	16


pare parts list	Forward Plate RV100

RV100



Item	Part No.	Name	Qty	L	С	SN INFO
10	PNNA	Engine withFrame	1			
20	PNNA	Base Plate with Exciter Unit	1			


Service, repair and wear part kits Kits-4812334803 Service, repair and wear part kits



Item	Part No.	Name	Qty	L	С	SN INFO
1	Service, repair and wear part kits	Service, repair and wear part kits				
1.1	4812334977	Repair kit, shock-absorber	1			


Item	Part No.	Name	Qty	L	С	SN INFO
1.2	4812334976	Repair kit, transmission	1			
1.3	4812334975	Repair kit, exciter unit	1			
1.4		Service kit	1			
2	Refurbishing kit	Refurbishing kit				
2.1	4812334974	Refurbishing kit - covering	1			
2.2	Refurbishing kit - decals	Refurbishing kit - decals	1			
3	Field kit	Field kit				
3.1	4812334980	Vulkollan Plate	1			
3.2	4812334979	Transport wheels	1			
3.3	4812334978	Comfort handle	1			
4	PNNA	Lubricants and operating substances				

Service, repair and wear part kits 4812334977 Repair kit, shock-absorber




Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086319	Rubber Mounting	2			
2	4812086320	Rubber Mounting	2			
3	4812086316	Hex.Head Screw	4			
4	4812086317	Spring Lock Washer	4			
5	4812086318	Plain Washer	4			

Service, repair and wear part kits 4812334976 Repair kit, transmission




Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086389	Centrifugal Clutch Assy.	1			
2	4812086372	Belt	1			
3	4812086337	Hex.Head Screw	1			
4	4812086119	Washer	1			
5	PNNA	Washer	1			
6	4812086418	Inner Belt Guard Assembly	1			
7	4812086339	Pvc Seal	1			
8	4812086245	Plain Washer	1			
9	4812086301	Spring Lock	1			
10	4812086337	Hex.Head Screw	1			
11	4812086329	Pulley	1			
12	4812086330	Washer	1			
13	4812086331	Schnorr Locking Washer	1			
14	4812086231	Hex. Head screw	1			
15	4812086169	Hex.Socket Set Screw With Cup Point	2			

Service, repair and wear part kits 4812334975 Repair kit, exciter unit




Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086323	Ball Bearing	2			
2	4812086325	Oil Seal	1			
3	4812086281	Key	1			
4	4812086322	O Ring	2			
5	4812086383	Oil Plug	2			

Refurbishing kits 4812334974 Refurbishing kit - covering




Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086421	Belt Guard Assembly	1			
2	4812086345	Hex.Head Screw	2			
3	4812086225	Spring Lock Washer	2			
4	4812334991	Washer	2			

Field kits 4812334980 Vulkollan Plat




Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086359	Vulkollan	1			
2	PNNA	Hex. Head screw	2			
3	4812086360	Bracket for Vulkollan	1			
4	PNNA	Self locking nut	2			

Field kits 4812334979 Transport wheels



Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086314	Wheel Axle Assembly	1			
2	4812086313	Wheel	2			
3	4812086190	Retaining Ring For Shaft	2			


Field kits 4812334978 Comfort handle




Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086423	Handle Complete Assembly	1			
2	4812086397	Rubber Mounting	2			
3	4812086398	Joining Plate	2			
4	4812334870	Spring Lock Washer	2			
5	PNNA	Hex.head screw	2			
6	4812086422	Handle pin	2			
7	4812086280	Hex.Nut With Plastic Insert	2			
8	4812086298	Nylon Bush	2			
9	4812086236	Locking pin with thread	1			
10	4812086237	Hex. nut	1			
11	4812086317	Spring Lock Washer	2			
12	4812334894	Hex.Head Screw	2			

Item	Part No.	Name	Qty	L	С	SN INFO
13	4812334870	Spring Lock Washer	2			
14	4812086229	Hex.Head Screw	2			
15	4812086277	Plain Washer	2			

Engine with Frame Engine with Frame






Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086396	Anti Vibration Stopper	2			
2	4812086317	Spring Lock Washer	2			
3	4812334894	Hex.Head Screw	2			
4	4812334870	Spring Lock Washer	2			
5	4812086229	Hex.Head Screw	2			
6	4812086423	Handle Complete Assembly	1			
7	4812086395	Engine Bolt Bracket Assembly	2			
9	4812086225	Spring Lock Washer	8			
10	4812086224	Hex.Head Screw	4			
11	4812086417	Cage Assembly	1			
12	4812086345	Hex.Head Screw	4			
13	4812086245	Plain Washer	7			
14	4812086301	Spring Lock	7			
15	4812334875	Flange Hex Nut	4			
16	4812086418	Inner Belt Guard Assembly	1			
17	4812086337	Hex.Head Screw	3			
18	4812086421	Belt Guard Assembly	1			


Item	Part No.	Name	Qty	L	С	SN INFO
19	PNNA	Plain Washer	2			
20	4812086339	Pvc Seal	1			
21	4812086387	Engine	1			
21.1	4812086350	Self Locking Nut	2			
22	4812086277	Plain Washer	2			
22	4812086314	Wheel Axle Assembly	1			
23	4812086313	Wheel	2			
24	4812086190	Retaining Ring For Shaft	2			
25	4812086389	Centrifugal Clutch Assy.	1			
26	PNNA	Washer	1			
27	4812086119	Washer	1			
28	4812086337	Hex.Head Screw	1			
29	4812086372	Belt	1			
30	PNNA	Set Deflector	1			


Engine with Frame Service parts




Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086311	Spark plug	1			
2	4812086410	Oil drain washer	2			
3	4812086411	Rope, Recoil starter	1			
4	4812086412	Element, Air cleaner(Dual)	1			
5	4812086413	Knob, Recoil starter	1			
6	4812086414	Knob, Reinforcement	1			

Base Plate with Exciter Unit Base Plate with Exciter Unit







Item	Part No.	Name	Qty	L	С	SN INFO
1	4812086315	Base plate assembly	1			
2	4812086186	Plug	1			
3	4812086301	Spring Lock	4			
4	4812086293	Hex. Head screw	4			
5	4812086321	Rear Cover	1			
6	4812086322	O Ring	2			
7	4812086323	Ball Bearing	2			
8	4812086324	Eccentric shaft	1			
9	4812086281	Key	1			
10	4812086325	Oil Seal	1			
11	4812086326	Front Cover	1			
12	4812086327	Conical Dented Washer	4			
13	4812086328	Countersunk Head Screw	4			
14	4812086169	Hex.Socket Set Screw With Cup Point	2			
15	4812086329	Pulley	1			
16	4812086330	Washer	1			
17	4812086331	Schnorr Locking Washer	1			

Item	Part No.	Name	Qty	L	С	SN INFO
18	4812086231	Hex. Head screw	1			
19	4812086319	Rubber Mounting	2			
20	4812086320	Rubber Mounting	2			
21	4812086318	Plain Washer	4			
22	4812086317	Spring Lock Washer	8			
23	4812086316	Hex.Head Screw	4			
24	4812086416	Engine box assembly	1			
25	4812086277	Plain Washer	4			
26	4812086346	Hex.Head Screw	4			
27	4812086423	Handle Complete Assembly	1			
28	4812086298	Nylon Bush	2			
29	4812086236	Locking pin with thread	1			
30	4812086237	Hex. nut	1			
31	4812086397	Rubber Mounting	2			
32	4812086398	Joining Plate	2			
33	4812334870	Spring Lock Washer	2			
34	PNNA	Hex.head screw	2			
35	4812086422	Handle pin	2			
36	4812086280	Hex.Nut With Plastic Insert	2			



